

# Aceptic Valves

## Series 191700 / 191800

### INDEX

1	Using FLOWSERVE valves, actuators and accessories correctly
2	Unpacking
3	Technical data
4	Safety
5	Installation
6	Disassembly and assembly
7	Disassembly
8	Assembly
9	Commissioning
10	Maintenance

## 1 USING FLOWSERVE VALVES, ACTUATORS AND ACCESSORIES CORRECTLY

### 1.1 Using

The following instructions are designed to assist in unpacking, installing and performing maintenance as required on FLOWSERVE products. Product users and maintenance personnel should thoroughly review this bulletin prior to installing, operating or performing any maintenance.

In most cases FLOWSERVE valves, actuators and accessories are designed for specific applications (e.g. with regard to medium, pressure, temperature). For this reason they should not be used in other applications without first contacting the manufacturer.

### 1.2 Terms concerning safety

The safety terms **DANGER**, **WARNING**, **CAUTION** and **NOTE** are used in these instructions to highlight particular dangers and/or to provide additional information on aspects that may not be readily apparent.



**DANGER:** indicates that death, severe personal injury and/or substantial property damage will occur if proper precautions are not taken.



**WARNING:** indicates that death, severe personal injury and/or substantial property damage can occur if proper precautions are not taken.



**CAUTION:** indicates that minor personal injury and/or property damage can occur if proper precautions are not taken.



**NOTE:** indicates and provides additional technical information, which may not be very obvious even to qualified personnel.

Compliance with other, not particularly emphasised notes, with regard to transport, assembly, operation and maintenance and with regard to technical documentation (e.g. in the operating instruction, product documentation or on the product itself) is essential, in order to avoid faults, which in themselves might directly or indirectly cause severe personal injury or property damage.

### 1.3 Protective clothing

FLOWSERVE products are often used in problematic applications (e.g. extremely high pressures, dangerous, toxic or corrosive mediums). In particular valves with bellows seals point to such applications. When performing service, inspection or repair operations always ensure, that the valve and actuator are depressurised and that the valve has been cleaned and is free from harmful substances. In such cases pay particular attention to personal protection (protective clothing, gloves, glasses etc.).

### 1.4 Qualified personnel

Qualified personnel are people who, on account of their training, experience and instruction and their knowledge of relevant standards, specifications, accident prevention regulations and operating conditions, have been authorised by those responsible for the safety of the plant to perform the necessary work and who can recognise and avoid possible dangers.

## 1.5 Installation



**DANGER:** Before installation check the order-no, serial-no. and/or the tag-no. to ensure that the valve/actuator is correct for the intended application.

Do not insulate extensions that are provided for hot or cold services.

Pipelines must be correctly aligned to ensure that the valve is not fitted under tension.

Fire protection must be provided by the user.

## 1.6 Spare parts

Use only FLOWSERVE original spare parts. FLOWSERVE cannot accept responsibility for any damages that occur from using spare parts or fastening materials from other manufactures. If FLOWSERVE products (especially sealing materials) have been on store for longer periods check these for corrosion or deterioration before using these products. Fire protection for FLOWSERVE products must be provided by the end user.

## 1.7 Service / repair

To avoid possible injury to personnel or damage to products, safety terms must be strictly adhered to. Modifying this product, substituting nonfactory parts, or using maintenance procedures other than outlined in this instruction could drastically affect performance and be hazardous to personnel and equipment, and may void existing warranties. Between actuator and valve there are moving parts. To avoid injury FLOWSERVE provides pinch-point-protection in the form of cover plates, especially where side-mounted positioners are fitted. If these plates are removed for inspection, service or repair special attention is required. After completing work the cover plates must be refitted.

Apart from the operating instructions and the obligatory accident prevention directives valid in the country of use, all recognised regulations for safety and good engineering practices must be followed.



**WARNING:** Before products are returned to FLOWSERVE for repair or service FLOWSERVE must be provided previously with a certificate which confirms that the product has been decontaminated and is clean. FLOWSERVE will not accept deliveries if a certificate has not been provided (a form can be obtained from FLOWSERVE).

## 1.8 Storage

In most cases FLOWSERVE products are manufactured from stainless steel. Products not manufactured from stainless steel are provided with an epoxy resin coating. This means that FLOWSERVE products are well protected from corrosion. Nevertheless FLOWSERVE products must be stored adequately in a clean, dry environment. Plastic caps are fitted to protect the flange faces to prevent the ingress of foreign materials. These caps should not be removed until the valve is actually mounted into the system.

## 1.9 Valve and actuator variations

These instructions cannot claim to cover all details of all possible product variations, nor in particular can they provide information for every possible example of installation, operation or maintenance. This means that the instructions normally include only the directions to be followed by qualified personal where the product is being used for is defined purpose. If there are any uncertainties in this respect particularly in the event of missing product-related information, clarification must be obtained via the appropriate FLOWSERVE sales office.


## 2 UNPACKING

Each delivery includes a packing slip. When unpacking, check all delivered valves and accessories using this packing slip.

Report transport damage to the carrier immediately.

In case of discrepancies, contact your nearest FLOWSERVE location.

**3 TECHNICAL DATA**



**Figure 1**

DN	A	B	C
	DIN 11850, Series 2	191700/191800	
10 / 3/8"	60	81	10
15 / 1/2"	60	81	16
20 / 3/4"	60	81	20
25 / 1"	65	81	26
32 / 1/4"	70	81	32
40 / 1/2"	75	82	38
50 / 2"	85	84	50
65 / 2 1/2"	100	105	66
80 / 3"	110	109	81
100 / 4"	120	115	100

- 3.1 Application** Control Valve
- 3.2 Pressure rating** PN 10
- 3.3 Temperature range** 0 °C to 100 °C
- 3.4 Valve function**

To ensure optimum valve function, observe the flow direction from connection **a** to connection **b**.

**3.4.1 Function: air-to-open – spring-to-close**

Product flow direction **a** ⇒ **b** (see fig. 1)  
Product flow direction closed by spring force.

**3.4.2 Function: spring-to-open – air-to-close**

Product flow direction **a** ⇒ **b** (see fig. 1)  
Product flow direction closed by air force.

**3.5 Material data**

**Seals in contact with the medium**

Valve plug	1.4435
Aseptic diaphragm	TFM / EPDM
Operating temperature	max. 100° C
Sterilisation temperature	130° C
Operating pressure	max. 1.6 Mpa

**Seals not in contact with the medium**

O-Rings	Silicon
---------	---------

**Stainless steels**

In contact with the medium	1.4404
Not in contact with the medium	1.4301

**3.6 CIP cleaning agents**

Nitric acid 3% / Temperature 80° C
Soda lye 3% / Temperature 80° C

**3.7 SIP sterilisation agents**

Hot water / Temperature 130° C
Steam / Temperature 130° C

**3.8 Surfaces**

In contact with medium	Ra ≤ 0,6 µm Ra ≤ 0,5 µm Elec.-polished (opt.) Ra ≤ 0,4 µm Elec.-polished (opt.)
Not in contact with medium	Metal, turned bright

**3.9 Valve connection piping**

**Installation position**

Vertical, to ensure valve and line drain free.

**3.10 Connection types**

- DIN 11850 series 2 (DN10 - 100) weld ends
- ISO 2037 / BS 4825 weld ends
- DIN EN ISO 1127 weld ends
- DIN 11864 Form A threaded connection
- DIN 11864 Form A flange connection
- DIN 32676 clamp connection
- ISO 2852 clamp connection

**3.11 Pipe connection**

Separable (for disassembly).

**3.12 Welding instruction**

See *welding instructions* (sec. 5.4).

**3.13 Installation**

See *assembly and disassembly instructions* (sec. 6).

**3.14 Electrical and pneumatic connections**

Assemble after fitting the valve.

**3.14.1 Electrical connections**



**WARNING:** Electrical connections to be made by a qualified electrician only.

- Observe valid VDE-EVU and other local regulations.
- Check operating voltage and amperage of specific parts before connection.

**3.15 Quality of supply air**

Pressure	6 bar (87 psi)
Solid particles	Particle size max. 5 mm (0.4 in.) Particle density max. 5 mg/m <sup>3</sup> (quality class 3)
Water content	Dew point +2° C (35.6 °F) (quality class 3)
Oil content	Oil free, max. oil content 25 mg/m <sup>3</sup> (quality class 3)

## 4 SAFETY

The valves described in this documentation are designed and produced so that they do not present any hazard for the operating and service personnel or for the system, in which the valves are installed, when handled properly observing all important instructions and safety precautions.

All installation and removal work, performed within the scope of maintenance or repair to the valves, should be accomplished only by trained personnel. When assembling or disassembling, observe the installation instructions. Proceed precisely as specified in the installation and removal instructions to prevent severe injury to the operating and service personnel.

The operator of the system is responsible for ensuring that the installation, operating and maintenance personnel assigned have the required qualifications. The operator is also responsible for ensuring that the personnel in question are familiar with the documentation and safety regulations.

The values listed in the chapter “*Technical Data*”, such as pressure, temperature, installation locations, etc., should be observed under all circumstances.

All materials and sealing elements must be suitable for these operating conditions and the media, with which the valves come into contact. The system operator is solely responsible for all risks and consequences resulting from failure to observe these operating parameters. Unauthorized modifications to the valves have an effect on the intended application and are not permissible.

In addition to these instructions, all local safety and accident prevention regulations apply.

## 5 INSTALLATION

### 5.1 General Instructions

We urgently recommend having the installation work accomplished by trained, expert personnel.

### 5.2 Delivery Status

The valves are tested at the factory and ready for installation when shipped. The valve can be connected to the product line with weld ends or selected pipe connections.

## 5.3 Installation Guidelines

### 5.3.1 Installation Space

Before starting installation determine and define the connection axes. Take installation dimensions from dimension drawings. Provide for space for operation as well as service.

### 5.3.2 Installation

Do not subject to pressure or tension.

### 5.3.3 Installation Position

Vertical, to ensure that valve and line run empty.

## 5.4 Welding Guidelines

Range of application	Welding between weld connections and piping acc. to DIN 11850 Series 2
Welding procedure	TIG (tungsten Inert gas welding)
Type of weld	<ul style="list-style-type: none"><li>• Prepare weld acc to DIN 2559 (joint shape I / for I-welds)</li><li>• Welds conforming to EN 25817 ⇒ evaluation group B (high) butt weld I-joint acc. to DIN 8532</li></ul>

### 5.4.1 Welding in valves

Installation state	Single-piece body
--------------------	-------------------



**CAUTION:** To prevent damage to sealing materials and functioning parts, always weld the body in a disassembled state. Disassemble according to disassemble instructions.

### 5.4.2 Preparation of weld

Cut off ends of pipe even and deburr. Adjust welding ends on housing so that they make radially and axially level contact with the piping (centering tool). Ensure that no gap is present at the welding ends in contact with each other, because otherwise the forming gas would flow out reducing the corrosion resistance of the weld.

### 5.4.3 Welding

Connect forming gas. Tack 3-4 points. TIG welding, manual or orbital (machine welding).

## 5.4.4 Welding fillers

Filler match-up table

Material to be welded	Suitable welding filler			
	1.4316	1.4430	1.4440	1.4519
1.4301	x			
1.4306	x			
1.4401		x		
1.4404		x		
1.4435		x	x	x
1.4571		x	x	

## 5.4.5 Final treatment of weld

### Interior area

Final treatment of weld not required. Surface quality can be improved at accessible points by grinding.

### Exterior areas

Final treatment process:

Pickling– brushing– grinding– polishing

## 5.5 Cleaning

Clean entire valve thoroughly before installing.

## 5.6 Installation

Install according to installation instructions.

## 6 DISASSEMBLY AND ASSEMBLY

(see fig. 2)

### 6.1 Installation

To remove the complete valve, separable connections must be provided in the vicinity of the valve connections **a** and **b**.

We recommend following distances from the valve:

Product inlet (**a**) : 1 x diameter

Product outlet (**b**) : 6 x diameter

### 7 DISASSEMBLY

Please observe separate documentation for disassembly of the actuator.



#### CAUTION:

*Before disassembly:*

*depressurise the line to atmospheric pressure and drain all fluid from the valve, close-off the supply air.*

**Valves with air-to-open actuators:** *tension the actuator springs using top handwheel or by applying supply air under the membrane.*

*Failure to do this will cause the valve bonnet to spring-out when the clamp is released due to the spring pressure acting between the plug and seat.*

*Observe electrical connection voltage, as necessary switch off power supply.*

7.1 Disconnect pneumatic and electrical feed lines.

7.2 On **air-to-open /spring-to-close** actuators tension actuator springs.

7.3 Remove actuator

Remove the coupling between the actuator stem and the plug stem (3). Loosen the slotted nut (M38 x 1.5) on the valve bonnet (2) and remove the actuator.

7.4 Release the tension on actuator springs.

7.5 Loosen and remove the TC clamp (3).



**CAUTION:** *Do not rotate the stem (3) while the diaphragm is clamped to the body. This can damage the stem and loosen the threaded connection between stem(3) and plug (10) and the valve will leak.*

7.6 Remove the bonnet (2) assy from the body (1).



**CAUTION:** *To avoid damage to the aseptic diaphragm (6) do not turn the bonnet.*

7.7 Pull the plug/stem and diaphragm assy. (4+6+10) out of the bonnet (2).

7.8 Carefully remove the wiper (5).

7.9 Remove the O-Ring (7) which serves as the stem seal (191800 only).

7.10 Remove the PTFE-guide (8) from the bonnet (2).

### 7.11 Disassemble the aseptic plug:

7.11.1 Using a suitable tool, loosen and remove the plug (10) from the stem (4).

7.11.2 Remove the diaphragm (6) from the stem (4)

7.11.3 Unscrew the diaphragm support ring (9) from the stem (4).

## 8 ASSEMBLY

Please observe separate documentation for assembly of the actuator.

Before assembly:

Thoroughly clean all surfaces.

8.1 Place O-Ring (7) in the bonnet (2) (191800 only).

### 8.2 Assemble the aseptic plug:

8.2.1 Screw the diaphragm support ring (9) onto the stem (4), the flat side towards the stem.

8.2.2 Place the diaphragm (10) on the plug with the convex side facing up.

8.2.3 Screw the plug (10) with diaphragm (6) onto the stem (4) and tighten to 25 Nm.

8.3 Place the wiper (5) in the bonnet (2).

8.4 Insert the PTFE-guide (8) carefully in the bonnet (2) and ensure it is seated correctly to prevent damage to the guide.

8.5 Insert the plug/stem and diaphragm assy. (4+6+10) into the bonnet (2).

8.6 Place the outside rim of the diaphragm (10) in the shoulder on the bonnet (2).



**CAUTION:** *Insert the bonnet straight. Ensure that the outside rim of the diaphragm is correctly seated in the groove in the bonnet. To avoid damage to the aseptic diaphragm (6) do not turn the bonnet.*

8.7 Place the bonnet assy. (2) on the body (1).

8.8 Replace the TC clamp (3) and tighten securely.

8.9 On **air-to-open /spring-to-close** actuators tension actuator springs.

8.10 Mount the actuator on the valve and secure with slotted nut (M38 x 1.5).

8.11 Attach the coupling between valve and actuator.

8.12 Release tension on the actuator springs.

8.13 Reconnect pneumatic and electrical feed lines and prepare the valve for cleaning.




Figure 2

## 9 COMMISSIONING



**CAUTION:** Ensure that no foreign particles are present in the line system

### 9.1 Idle test

Operate valve once by actuating with compressed air, while checking mechanical function of valve.

- TC clamp (3) seated tightly
- Check air pressure and air connections for leakage
- Check stroke path; valve spindle (4) should open and close without jerking

Check function of the actuator based on documentation for actuator.

Clean system before operating with product for the first time.

### 9.2 Test Run under Operating Conditions

Check sealing elements for leakage.  
 Replace defective seals as described in installation and removal instructions.  
 Check mechanical functions (see idle test).  
 Check function of control drive (see idle test).

### 9.3 Initial Operation

Check valve function analog to test criteria for test run.

### 9.4 Malfunctions

Eliminate any malfunctions, which occur immediately according to installation and removal instructions.

### 9.5 Malfunctions

Eliminate any malfunctions, which occur immediately according to installation and removal instructions.

## 10 MAINTENANCE

### Before maintenance



**CAUTION:**

**Valves with air-to-open actuators:** tension the actuator springs using top handwheel or by applying supply air under the membrane.

Failure to do this will cause the valve bonnet to spring-out when the clamp is released due to the spring pressure acting between the plug and seat. Observe electrical connection voltage, as necessary switch off power supply.

Have repair work performed only by trained personnel authorised by the operator.

## 10.1 Inspection

FLOWSERVE valves do not require any special service. However perform a visual check for leakage and proper function between the maintenance intervals.

## 10.2 Maintenance

Maintenance intervals based on the actual operating conditions can only be determined by the user/operator, because they depend on the following application parameters:

- Operating time per day
  - Switching intervals
  - Type of product
- Type of cleaning (CIP / SIP)

We recommend the following data as guide values:

- For liquids with solid constituents and temperatures of 80° C to 100° C:  
approx. every 3 – 6 months
- For liquids with solid constituents and temperatures of approx. 60° C:  
approx. every 12 months
- For liquids without solid constituents and temperatures of max. 95° C:  
approx. every 24 months

Intervals of 12 months are recommended for cleaning systems.

Naturally, the specified values assume that the sealing material is resistant to any chemicals used in cleaning.

### Regional Headquarters

#### Flowserve EMA

Burrell Road, Hayward Heath  
West Sussex, RH16 1TL  
England  
Telephone: +44 (0) 1444 314400  
Facsimile: +44 (0) 144 3144401

#### Flowserve America

1350 N. Mt. Springs Prkwy.  
Springville, UT 84663  
USA  
Telephone: +1 801 489 8611  
Facsimile: +1 801 489 3719

#### Flowserve Asia

12 Tuas Avenue 20  
638824  
Republic of Singapore  
Telephone: +65 862 3332  
Facsimile: +65 862 4940

### Main Sales Offices EMA (Europe, Middle East, Africa)

#### Flowserve France

7 Avenue de la Libération  
63300 Thiers Cedex  
France  
Telephone: +33 (0) 4 73 80 42 66  
Facsimile: +33 (0) 4 73 80 14 24

#### Flowserve UK

Station Road  
Persore, Worcestershire  
England WR102BZ  
Telephone: +44 (0) 1386 55 45 51  
Facsimile: +44 (0) 1386 55 49 68

#### Flowserve Switzerland

Allee du Quartz 1  
CH-2300 La-Chaux-de Fonds  
Switzerland  
Telephone: +41 (0) 32 925 9700  
Facsimile: +41 (0) 32 926 5422

#### Flowserve Germany

Manderscheidstr. 19  
45141 Essen  
Germany  
Telephone: +49 (0) 201 8919 5  
Facsimile: +49 (0) 201 8919 662

#### Flowserve South Africa

Units 1 and 2  
26, Imvuba Road, Sebenza Ext 6  
Edenvale, Gauteng  
Edenglen 1613  
South Africa  
Telephone: +27 11 609 2094  
Facsimile: +27 11 609 3735

#### Flowserve Middle-East

C/O Saleh & Abdulaziz Abahsain  
P.O. Box 209

Al Khobar 31952  
Saudi Arabia  
Telephone: 9663 857 3442  
Facsimile: 9663 859 5284

#### Flowserve Austria

Kasernengasse 6  
  
9500 Villach  
Austria  
Telephone: +43 (0) 424241 181-0  
Facsimile: +43 (0) 424241 181 50/51

#### Flowserve Benelux

Van Leeuwenhoekweg 6  
  
3225 LX Hellevoetsluis  
The Netherlands  
Telephone: +31 (0) 181 330044  
Facsimile: +31 (0) 181 330040

#### Flowserve Italy

Via Prealpi, 30  
Cormano (Milano)  
Italy  
Telephone: +39 (0) 2663251  
Facsimile: +39 (0) 26151863

#### Flowserve Spain

Luis Cabrera, 86-88  
E-28002 Madrid  
Spain  
Telephone: +34 9 15 152 032  
Facsimile: +34 9 14 136 747

#### Flowserve Portugal

Av. Dr. Antunes Guimaraes, 1159  
Porto 4100-082  
Portugal  
Telephone: +351 22 619 8770  
Facsimile: +351 22 619 7575

#### Flowserve Scandinavia

Gelbgjutaregatan  
58933 Linköping, Östergötland  
Sweden  
Telephone: +46 13 316100  
Facsimile: +46 13 136054

#### Flowserve Eastern Europe

12, av. du Québec  
91965, Courtaboeuf Cedex  
France  
Telephone: +33 (0) 1 60 923 251  
Facsimile: +33 (0) 1 60 923 299

All data subject to change without notice

©01.2003 Flowserve Corporation. Flowserve and Kämmer are trademarks of Flowserve Corporation