

OPERATING MANUAL

ba77065e02 04/2017



VisoTurb[®] 900-P

DIGITAL TURBIDITY SENSOR



a **xylem** brand



The most current version of the present operating manual
is available on the Internet under www.WTW.com.

Copyright

© Weilheim 2017, WTW GmbH

Reproduction in whole - or even in part - is prohibited without the
express written permission of WTW GmbH, Weilheim.

Printed in Germany.


VisoTurb® 900-P - Contents

1	Overview	4
1.1	Structure and function	4
1.2	Recommended fields of application	4
2	Measurement / Operation	5
2.1	General information	5
2.2	Commissioning	5
2.3	Opening and closing the IDS plug connection	6
2.4	Measuring	7
2.5	Calibration	7
2.6	Storing	7
3	Cleaning	7
4	What to do if ...	8
5	Technical data	8
5.1	General data	8
5.2	Measuring ranges, resolution, accuracy	10
5.3	Accuracy of the IDS measuring technique	10
6	Wear parts and accessories	10

1 Overview

1.1 Structure and function

Structure



- | | |
|---|---|
| 1 | Shaft |
| 2 | Connecting head with active electronics |
| 3 | IDS plug |

Automatic sensor recognition

The sensor electronics with the stored sensor data is in the connecting head. The data include, among other things, the sensor type and series number. With each calibration, the calibration data are written in the sensor and the calibration history is recorded. The data are recalled by the meter when the sensor is connected and are used for measurement and for measured value documentation. Storing the calibration data in the sensor ensures that the correct calibration data are automatically used if the sensor is operated with several meters.

The digital transmission technique guarantees the failure-free communication with the meter even with long connection cables. The sensor firmware can be updated with the aid of the meter if the firmware is enhanced by WTW.

1.2 Recommended fields of application

- On site measurements in rivers, lakes and wastewater
- Ground water measurements
- Applications in water laboratories

2 Measurement / Operation

2.1 General information

The measured turbidity value is affected by:

- Gas bubbles (e.g. air bubbles) in the test sample.
- The measuring environment (reflective objects, incidence of light)

The following actions serve to avoid malfunctions:

- When immersing the sensor in the test sample, hold the sensor at an angle.
- Prior to measurement, do not move or shake the test sample.
- Keep 6 cm distance between the sensor and the bottom of the measuring vessel.
- Keep 2 cm distance between the sensor and the lateral walls of the measuring vessel.
- Use a lightproof bottle for measuring.

Gas bubbles (e.g. air bubbles)

Reflection

Incidence of light

Suitable vessels for measurement and calibration

Measure and calibrate in lightproof bottles with approx. 6 cm diameter and a filling level of at least 8 cm.

Suitable measurement and calibration bottles are listed in the price list of the WTW catalog "Lab and Field Instrumentation".

2.2 Commissioning

Scope of delivery


- Turbidity sensor VisoTurb® 900-P
- Operating manual

Getting the sensor ready for measuring

Connect the sensor with a free IDS connector of the meter. Please note the information on how to open and close the IDS plug connection given in section 2.3 OPENING AND CLOSING THE IDS PLUG CONNECTION.
The sensor is immediately ready to measure.

Connecting cables in various lengths to connect the sensor to the meter are listed in chapter 6 WEAR PARTS AND ACCESSORIES.

2.3 Opening and closing the IDS plug connection



Opening the plug connection

- If necessary, clean the plug connection
- Open the locking device (step 1)
- Press the clips of the coupling together with your thumb and forefinger and pull the coupling out of the plug (step 2).

Closing the plug connection

- Make sure that the plug connection is perfectly dry and clean.
- Align the guidance of the coupling to the groove in the plug and insert the coupling into the unlocked plug up to the stop (step 3)
- Close the locking device (step 4)

2.4 Measuring

Minimum distance

If the distance between the sensor and any reflecting surfaces (walls and bottom of the vessel) is too small, this will affect the measurement result. Keep the following minimum distance for optimum measurement results:

- Keep 2 cm distance between the sensor and the walls of the measuring vessel.
- Keep 6 cm distance between the sensor and the bottom of the measuring vessel.

2.5 Calibration

When is calibrating useful?

Calibrating can be useful in the following special cases:

- If the measured values seem to be implausible
- Routinely within the framework of the company quality assurance

2.6 Storing

Always store the sensor at a temperature in the range -20 ... +80 °C.

3 Cleaning

CAUTION

To clean the sensor, disconnect it from the instrument.



Exterior cleaning

We recommend cleaning the sensor thoroughly, especially before measuring low turbidity values.

Contamination	Cleaning procedure
Lime sediments	Immerse in acetic acid for 5 minutes (volume share = 10 %)
Fat/oil	Clean with warm water that contains washing-up liquid

After cleaning, thoroughly rinse with deionized water and recalibrate if necessary.

Aging of the turbidity sensor

Normally, the turbidity sensor does not age. Special measuring media (e.g. strong acids and bases, organic solvents) or temperatures that are too high may considerably reduce its lifetime or lead to damage. The warranty does not cover failure caused by measuring conditions and mechanical damage.

Disposal

We recommend to dispose of the measuring cell as electronic waste.

4 What to do if ...


Error symptom	Cause	Remedy
No turbidity display	<ul style="list-style-type: none"> – No connection between meter and turbidity sensor – Cable defective 	<ul style="list-style-type: none"> – Establish connection between meter and turbidity sensor
Implausible turbidity values	<ul style="list-style-type: none"> – There are gas bubbles (e.g. air bubbles) in front of the measurement window – Incorrect calibration, e.g.: <ul style="list-style-type: none"> – Unsuitable calibration standard solutions (e.g. too old) – Unsuitable calibration environment (e.g. due to gas bubbles, reflection, light) 	<ul style="list-style-type: none"> – Remove the gas bubbles, e.g. by immersing the sensor at an angle – Check the calibration
Error message, OFL	<ul style="list-style-type: none"> – Measured value outside the measuring range 	<ul style="list-style-type: none"> – Select a suitable measuring medium
Measured values too low	<ul style="list-style-type: none"> – Measurement window soiled 	<ul style="list-style-type: none"> – Clean the measurement window
Measured values too high	<ul style="list-style-type: none"> – Reflection at the walls or bottom of the measuring vessel – Incidence of light 	<ul style="list-style-type: none"> – Keep the minimum distance of the sensor towards the walls and bottom of the measuring vessel (see section 2.4) – Use a light-proof measuring vessel

5 Technical data

5.1 General data

General features	Measuring principle	Nephelometric according to ISO 7027 / DIN EN 27027
	Wavelength:	860 nm ± 15 nm
	Light source	Infrared LED

Dimensions
(in mm)



Weight	Approx. 83 g (without cable)	
Materials	Shaft	Titanium
	Connection head	POM
IDS plug	Connection type	4-pin, watertight plug connection with locking device, reverse polarity protected
	Materials	<ul style="list-style-type: none"> - Plastic parts: Fiber-glass reinforced Noryl, TPU, TPC-ET, POM, PEEK, PBT - O-ring: FPM - Contacts gold-plated
Pressure resistance	Sensor with connection cable	IP 68 (10×10^5 Pa or 10 bar)
	Cable plug	IP 67 (when plugged in)
<p>The VisoTurb® 900-P meets the requirements according to article 3(3) of the directive, 97/23/EC ("pressure equipment directive").</p>		
Measurement conditions	Turbidity measuring range	0.0 ... 4000.0 FNU/NTU
	Temperature range	-5 ... 50 °C (23 ... 158 °F)
	Max. admissible overpressure	10×10^5 Pa (10 bar)
	Minimum depth of immersion	2 cm
Storage conditions	Recommended storing method	In air
	Storage temperature	-20 ... 80 °C
Characteristics when delivered	Responding behavior	t63 (63 % of the final value display after) < 2 s

5.2 Measuring ranges, resolution, accuracy

Measuring ranges, resolution	Measured parameter	Measuring range	Resolution (max.)
	FNU/NTU	0.0 ... 4000.0	0.1

5.3 Accuracy of the IDS measuring technique

Measured parameter	Measuring range	Accuracy (± 1 digit)
FNU/NTU	0.0 ... 999.9	0.3 FNU or ± 2 % of the measured value (depending on the greater value)
	1000.0 ... 4000.0	± 5 % of measured value

6 Wear parts and accessories

Accessories for VisoTurb® 900-P	Description	Model	Order no.
	IDS connecting cable, 1.5 m	AS/IDS-1.5	903 850
	IDS connecting cable, 3 m	AS/IDS-3	903 851
	IDS connecting cable, 6 m	AS/IDS-6	903 852
	IDS connecting cable, 10 m	AS/IDS-10	903 853
	IDS connecting cable, 15 m	AS/IDS-15	903 854
	IDS connecting cable, 20 m	AS/IDS-20	903 855
	IDS connecting cable, 25 m	AS/IDS-25	903 856
	IDS connecting cable, 40 m	AS/IDS-40	903 857
	IDS connecting cable, 60 m	AS/IDS-60	903 858
	IDS connecting cable, 100 m	AS/IDS-100	903 859
	Kit for turbidity calibration Turbidity standards 124.0 FNU/NTU and 1010.0 FNU/NTU)	Cal-Kit VT900	600 702
	Calibration and measurement bottle, 0.5 l	SB VT 900	600 704
	Protective armouring (/K variant) (The /S variant has an impact on the measured value.)	A 925-P/K	903 839



Further accessories are listed in the price list of the WTW catalog "Lab and Field Instrumentation".

What can Xylem do for you?

We're a global team unified in a common purpose: creating innovative solutions to meet our world's water needs. Developing new technologies that will improve the way water is used, conserved, and re-used in the future is central to our work. We move, treat, analyze, and return water to the environment, and we help people use water efficiently, in their homes, buildings, factories and farms. In more than 150 countries, we have strong, long-standing relationships with customers who know us for our powerful combination of leading product brands and applications expertise, backed by a legacy of innovation.

For more information on how Xylem can help you, go to xyleminc.com.



Service address:

Xylem Analytics Germany

Sales GmbH & Co. KG

WTW

Dr.-Karl-Slevogt-Str. 1

82362 Weilheim

Germany

Tel.: +49 881 183-325

Fax: +49 881 183-414

E-Mail wtw.rma@xyleminc.com

Internet: www.WTW.com



Xylem Analytics Germany GmbH
Dr.-Karl-Slevogt-Str. 1
82362 Weilheim
Germany